

OPERATION AND MAINTENANCE MANUAL

microtuf[®]

MODEL FS4200 SERIES – MASS FLOW SWITCH

MODEL LS3200 SERIES – POINT LEVEL SWITCH

DOCUMENT 3242-OM-12

REVISION 12

DECEMBER 2012

DELTA M CORPORATION[®]

1003 LARSEN DRIVE

OAK RIDGE, TENNESSEE 37830

PH 865-483-1569

FAX 865-483-1142

TOLL FREE 800-922-0083

www.deltamcorp.com

email: service@deltamcorp.com

PROPRIETARY INFORMATION

THIS DOCUMENT IS THE PROPERTY OF DELTA M CORPORATION AND MAY CONTAIN INFORMATION COVERED BY PATENTS AND/OR CONSIDERED CONFIDENTIAL. UNLESS RIGHTS ARE EXPRESSLY GRANTED BY WRITTEN PERMISSION OF DELTA M CORPORATION, THIS INFORMATION IN WHOLE OR IN PART MAY NOT BE DISCLOSED OR USED IN THE DESIGN, SALE, MANUFACTURE, TEST, OR SUPPLY OF THE SAME OR SIMILAR PRODUCTS.

MODEL NO. _____ SERIAL NO. _____

DATE OF SHIPMENT _____ INSTALLATION DATE _____

CUSTOMER TAG NO. _____ PO NO. _____

OPTIONS _____

SPECIAL NOTES _____

BEFORE STARTING

DELTA M appreciates your choosing our product for your liquid level or liquid/gas flow switching application. We are committed to providing reliable, quality instrumentation to our customers.

To ensure the maximum and intended benefit of this instrument, we encourage you to read this brief operation and maintenance manual in its entirety prior to unpacking and installing the unit.

The following precautions should be noted immediately:

- φ **WHEN INSTALLING YOUR DELTA M SWITCH INTO A PIPE OR VESSEL, USE A 1 1/8 INCH (28.575mm) OPEN-END OR ADJUSTABLE WRENCH TO TIGHTEN AT THE HEX FLATS OF THE MNPT OF A STANDARD SWITCH. (IF YOU HAVE A NON-STANDARD SWITCH AN ALTERNATE SIZE WRENCH MAY BE REQUIRED). DO NOT USE THE INSTRUMENT HEAD TO TIGHTEN THE SWITCH TO THE MOUNTING PORT. ROTATION OF THE INSTRUMENT HEAD WITH RESPECT TO THE SENSOR BODY CAN CAUSE INTERNAL WIRING DAMAGE (SEE FIGURES 1A, 1B, AND 1C).**
- φ **THE SWITCH BODY MUST BE ORIENTED TO HAVE THE TWIN SENSORS PARALLEL TO THE LEVEL BEING DETECTED WHEN THE SENSOR IS INSTALLED HORIZONTALLY FOR POINT LEVEL APPLICATIONS. LIKewise, FOR FLOW APPLICATIONS, THE SWITCH BODY MUST BE ORIENTED TO HAVE THE TWIN SENSORS PERPENDICULAR TO THE FLOW BEING DETECTED. DUE TO THE PIPE THREAD MOUNTING, IT MAY BE NECESSARY TO MAKE A TRIAL FIT, ADD OR REMOVE TEFLON TAPE OR OTHER PIPE THREAD SEALANT, AND REINSTALL TO ACHIEVE A SATISFACTORY SEAL WITH THE SENSORS PROPERLY ORIENTED. FOR VERTICAL INSTALLATION OF SENSORS FOR POINT LEVEL DETECTION THE ORIENTATION MAKES NO DIFFERENCE. PROPER ORIENTATION IS MARKED ON THE SWITCH BODY FOR REFERENCE (SEE FIGURE 5).**
- φ **A GROUND WIRE MUST BE ATTACHED TO THE GROUND SCREW LOCATED INSIDE THE INSTRUMENT ENCLOSURE FOR PROPER OPERATION. FOR CENELEC/CE OPTION THE GROUND SCREW IS LOCATED OUTSIDE THE BODY OF THE INSTRUMENT ENCLOSURE (SEE FIGURE 6).**
- φ **FOR OPTIMUM PERFORMANCE OF THE DELTA M THERMAL FLOW SWITCH, THE RECOMMENDED LOCATION OF THE SENSOR SHOULD BE IN A STRAIGHT RUN, FREE OF OBSTRUCTION FOR TEN (10) TIMES THE PIPE DIAMETER UPSTREAM OF THE SENSOR, AND FIVE (5) TIMES THE PIPE DIAMETER DOWNSTREAM OF THE SENSOR.**
- φ **BE SURE TO APPLY THE PROPER VOLTAGE AS CONFIGURED AT THE FACTORY. DO NOT APPLY 115 VAC TO 24 VDC VERSIONS OR 24 VDC TO 115 VAC VERSIONS. (LIKewise 230 VAC).**
- φ **FOR OPTIMUM OPERATION, CALIBRATION MUST BE ACCOMPLISHED AT ACTUAL PROCESS TEMPERATURE AND PRESSURE CONDITIONS IN GASES AND AT ACTUAL PROCESS TEMPERATURE CONDITIONS IN LIQUIDS.**
- φ **TO ENSURE ACCURATE CALIBRATION AND AVOID SET POINT DRIFT, IT IS IMPERATIVE THAT A MINIMUM OF 10 MINUTE WAIT BE OBSERVED AFTER POWER IS APPLIED TO ALLOW THE SENSOR TO WARM-UP TO THE AMBIENT FLUID TEMPERATURE.**

LIKELIKE, WHEN ADJUSTING THE ZERO, SPAN, AND SET POINTS POTS, A MINIMUM OF 30 SECONDS SHOULD BE OBSERVED TO ALLOW FOR STABILIZATION OF TEMPERATURE.

φ **DO NOT SANDBLAST OR ABRASIVE CLEAN THE SENSING PROBES. THE SENSING PROBES COULD BE DAMAGED BY ABRASIVES.**

■ **ALL DIMENSIONS GIVEN IN THIS MANUAL ARE IN INCHES (AND MILLIMETERS).**

If you have any questions prior to or during installation and calibration, please do not hesitate to call the factory for assistance. We want to ensure the very best possible installation and operational results for your benefit.

NOTICE

This manual covers the following model numbers:

microtuf® Series Models		FS4200	LS3200
Agency Approvals Switch	Explosion-Proof rating	Mass Flow Switch	Point Level
CENELEC European	EEx d IIB T4 (Killark Enclosure) EEx d IIC T4 (Akron Electric Enclosure) See Figure 1A and 1B	FS42CN	LS32CN
CSA Canadian Standards	T4A Class I, Group B,C,D Class II, Group E,F,G (Both Akron Electric and Killark)	FS42CS	LS32CS
Non-Approved	Non-Explosion Proof	FS42NX	LS32NX
Switch Kits (No Enclosures)	Not Rated	FS42SK	LS32SK
CE (Ref. Section 3.2.3 Wiring)	EMC Directive: 89/336/EEC	Option – CE	Option -CE

SPECIAL NOTICE

The electronic assemblies contained in the microtuf[®] models are configured for specific voltages and have specific modifications to accommodate the various agency approvals. When ordering spare electronics, replacements, or exchanges in the field please ensure you identify the specific configuration you have by noting the boxes marked on the transformer configuration tag.

PN 200203			
 <input type="checkbox"/>		24 VAC	<input type="checkbox"/>
 <input type="checkbox"/>		24 VDC	<input type="checkbox"/>
 <input type="checkbox"/>			
SN <input type="text"/>		<input type="checkbox"/>	220 VAC
		<input type="checkbox"/>	<input type="checkbox"/>

WARNING

THE WETTED SENSOR OF THE SWITCH IS OF AN ALL WELDED CONSTRUCTION CREATING A PRESSURE BOUNDARY FROM THE PROCESS FLUID (LIQUID OR GAS). ANY BREACH OF THIS BOUNDARY THROUGH CORROSION, MISTREATMENT, OR MISAPPLICATION COULD ALLOW THE PROCESS FLUID TO ENTER THE ENCLOSURE OF THE UNIT.

PROCEED WITH CAUTION WHEN OPENING THE ENCLOSURE AFTER A BREACH OF THE PRESSURE BOUNDARY TO AVOID CONTACT WITH ANY PROCESS FLUIDS THAT MAYBE CONTAINED WITHIN THE ENCLOSURE.

CAUTION

IF THE FLUID PROCESS TEMPERATURE EXCEEDS 40 DEG C, THIS INSTRUMENT CANNOT BE USED IN AN EXPLOSION PROOF APPLICATION UNLESS THE IGNITION TEMPERATURE OF THE FLUID ATMOSPHERE IS A MINIMUM OF 80 DEG C HIGHER THAN THE PROCESS TEMPERATURE.

TABLE OF CONTENTS

1.0	INTRODUCTION
2.0	DESCRIPTION
2.1	LEVEL SWITCHING
2.2	FLOW SWITCHING
3.0	INSTALLATION
3.1	MECHANICAL INSTALLATION
3.2	ELECTRICAL INSTALLATION
3.2.1	LOCAL ELECTRONICS (LE OPTION/STANDARD)
3.2.2	REMOTE ELECTRONICS (RE) OPTION
3.2.3	CE OPTION FILTER BOARD CONNECTOR PLATE WIRING (CE OPTION)
4.0	OPERATION AND CALIBRATION OF THE microtuf® SWITCH FOR FLOW APPLICATIONS
4.1	PRE-OPERATIONAL CHECKS
4.2	L.E.D. AND RELAY STATUS LOGIC (FAIL-SAFE)
4.3	CALIBRATION – FLOW
5.0	OPERATION AND CALIBRATION OF THE microtuf® SWITCH FOR POINT LEVEL APPLICATIONS
5.1	PRE-OPERATIONAL CHECKS
5.2	L.E.D. AND RELAY STATUS LOGIC (FAIL-SAFE)
5.3	CALIBRATION – LEVEL
6.0	MAINTENANCE AND TROUBLE SHOOTING
6.1	CLEANING
6.2	TROUBLE SHOOTING
6.2.1	POWER AND CONTINUITY VERIFICATION
6.2.2	SENSOR/ELECTRONICS FUNCTIONALITY VERIFICATION
6.2.3	SET POINT DRIFT
7.0	SPECIFICATIONS
8.0	WARRANTY AND SERVICE
8.1	WARRANTY
8.2	SERVICE
8.3	SPARE PARTS LIST
9.0	APPENDIX
9.1	VOLUME FLOW CONVERSION CHART
9.2	FLOW CONVERSION CHART
9.3	FLOW OF WATER THROUGH SCHEDULE 40 STEEL PIPE (<i>AVAILABLE IN PRINTED</i>)

MANUAL ONLY)

9.4 MODEL NUMBER DESIGNATION AND AVAILABLE OPTIONS

10 OPTIONS

- 10.1 LIVETAP (LT)
- 10.2 VARIABLE INSERTION (VI)
- 10.3 THERMOCOUPLE OUTPUT (TO)
- 10.4 RTD OUTPUT(RT)
- 10.5 SANITARY (3A1)
- 10.6 SP76 MANIFOLD (S76)
- 10.7 TANK LOADING PROBE (TLP)
- 10.8 LOW FLOW SENSOR (LFS)
- 10.9 LIQUID LEVEL MULTI-POINT (MD/MP)
- 10.10 SWITCH KITS (SK)



1.0 INTRODUCTION

The DELTA M microtuf[®] Switch is the state-of-the-art in gaseous and liquid flow switching or liquid level control. Flow or level detection is accomplished by using a high resolution **thermal differential** technique. The sensor wetted parts are of durable 316L series stainless steel, all welded construction with no moving parts. The switch is easy to install and adjust, giving reliable, low maintenance performance in the most demanding applications.

2.0 DESCRIPTION


The microtuf[®] Switch uses a **thermal differential** technique to sense changes in the heat transfer characteristics of a media. Figures 1A and 1B show the outline of the microtuf[®] Switch. The sensor consists of a pair of matched, Resistance Temperature Detectors (RTD's) encased in twin 316L series stainless steel tubes. One RTD is self-heated using a constant DC current. The other RTD is unheated to provide an accurate process temperature reference. The **thermal differential** created between the heated and reference RTD pair is a function of the density and/or velocity of the media with which the sensor is in contact. Other physical properties may have a secondary effect as well. The differential is greatest at a no flow (or dry) condition and decreases as the rate of flow increases (or as a liquid quenches the sensor/wet condition).

The DELTA M Corporation sensor excitation method relies on constant current to the heated and reference sensors. Thus power to the heated sensor is not constant but changes linearly with temperature as the sensor resistance changes. Temperature compensation is accomplished by using the amplified reference sensor voltage which also changes linearly with temperature, as a dynamic reference. During calibration dry/no flow and wet/full flow conditions are impressed across the trip point potentiometer. Since this reference is not fixed but is set with respect to the reference sensor voltage, as temperature changes the trip point potentiometer voltage changes with temperature exactly the same as that of the heated sensor voltage with which it is being compared. Thus full temperature compensation is achieved with non constant power.



DIMENSIONS IN INCHES (MILLIMETERS)

FIGURE 1A LS3200/FS4200 microtuf® OUTLINE DIAGRAM STANDARD 2.0 INCH INSERTION (KILLARK ENCLOSURE – NEMA 4-EEXd 11B, T4) (MTF1A00.DWG/.FCW)



DIMENSIONS IN INCHES (MILLIMETERS)

DRAWING FILE: CIXI.DWG

FIGURE 1C

LS3200/FS4200 microtuf® OUTLINE DIAGRAM STANDARD 2.0 INCH INSERTION (CIXI ENCLOSURE – NEMA 4X)(CIXI.DWG)

2.1 Level Switching

The thermal differential created between the heated and reference unheated RTD pair is a function of the liquid or gas medium with which the sensor is in contact.

The point level measurement application uses the heat transfer differences between two media to detect liquid level. For example, air has a relatively poor heat transfer characteristic so the heated sensor will become relatively hot. If the sensor is then immersed in water, the relatively high heat transfer characteristics of water will cool the heated RTD surface causing a decrease in the signal output.

This same rational applies for any two media in contact with the sensor. Each medium will have its own characteristic heat transfer properties. As long as there is a reasonable difference in the heat transfer properties between the two media, the microtuf[®] can discriminate between them. Figure 2A shows the relative signal output of the microtuf[®] sensor to a range of different media. The maximum difference in output occurs between vacuum and liquid metal. However, a significant difference occurs between water and hydrocarbon liquids so the microtuf[®] can be used to detect a water/hydrocarbon liquid-liquid interface. In general, the interface between any two media with differing heat transfer properties can be detected.

Thermal Differential Theory of Operation

Liquid level




Note: Probe tips contain matched RTD's one of which is self-heated with about 400mw of power. The other provides temperature compensation



The heated RTD responds to the heat transfer coefficient of the media with which it is in contact. Gases with low heat transfer result in a high differential temperature between the heated and reference tips

When the heated tip makes contact with a liquid with higher heat transfer the differential temperature drops and the lower differential results in a switch trip to indicate liquid

FIGURE 2A: RELATIVE CHANGE IN RESPONSE OF A HEATED RTD IMMERSSED IN VARIOUS MEDIA




DRAWING FILE: MTF2A0.DWG

2.2 Flow Switching


Most mass flow monitoring techniques calculate mass indirectly by measuring volumetric flow such as gallons per minute or cubic cm per second, then either measure density separately or calculate it from temperature measurements of the fluid and, finally, combine density and volumetric flow to obtain mass flow. The DELTA M thermal-differential technique is one of two methods that directly measure the mass flow. For ease of comparison most flow applications are presented in terms of velocity which is independent of the flow cross sectional area (i.e. feet per second (FPS)). The true mass flow equivalent would be FPS multiplied by density but for simplicity FPS is used and density effects are ignored. This is normally not critical for flow switching applications.

When the sensor is inserted into a liquid or gas the heated RTD is strongly affected by the velocity of the medium. Flow past the heated RTD changes the heat transferred from the surface of the sensor. This cooling effect reduces the temperature of the sensor. The microtuf[®] compares this change to a preset flow trip point to switch the output. Figure 2B shows the model FS4200 signal change vs. flow rate for air, light hydrocarbon liquids, and water. The signal change vs velocity has the same general shape for all three media but the change is larger for air and the sensitive range is different for each. For air and most gaseous media the range is 0.1 to 500 feet per second (FPS). For most liquid media the

range is 0.01 to 5 FPS (Hydrocarbons) and 0.01 to 2.5 FPS (water). Appendices in section 9.0 contain flow conversion information to facilitate conversion from various units and pipe dimensions into flow velocity in feet per second.




For a no flow condition the thermal differential between the two tips is high because of relatively low heat transfer.




When the lower differential matches the customer select flow velocity trip point (set point) the switch relay and red LED are tripped.

Gas Or Liquid Flow

Note: The fluid velocity and heat absorption ability determine the differential between the tips. Their combination determines the measurable velocity. In water velocities from 0.01 to 2.5 FPS are measurable. In Hydrocarbons velocities from 0.01 to 5 FPS are measurable, whereas in air velocities of 0.1 to 500 FPS can be measured.



Flow across the tips decreases the thermal differential because of the higher heat transfer of flowing fluids. This differential is compared with the trip point.



When flow is above the trip point the differential is smaller than at the set point and the relay and LED remain tripped.





FIGURE 2B microtuf® MODEL FS4200 FLOW RESPONSE FOR THREE MEDIA

Figure 3.A shows a block diagram of the microtuf® switch.

Once the switch is set to respond to the minimum and maximum flow rates (or wet vs. dry conditions), the trip point is set by adjusting the Trip Adjust Potentiometer. Solid state electronics transform the flow (or wetting) induced temperature differential into a voltage that is compared to a control voltage. Matching voltages cause actuation of a relay to indicate a change in state (flow vs. no-flow or dry vs. wet).



DRAWING FILE: MTF3A00.DWG/.FCW

FIGURE 3A: MICROTUF SERIES SWITCH BLOCK DIAGRAM
 MODELS LS32CS/FS42CS, LS32CN/FS42CN, LS32NX/FS42NX,
 AND LS32SK/FS42SK
 (MTF3A00.DWG/.FCW)

Figure 3B shows a block diagram of the microtuf® switch with the addition of an EMC filter required for the CE options (see section 7.0).




FIGURE 3B: MICROTUF MODELS WITH THE CE OPTION SWITCH BLOCK DIAGRAM (MTF3B00.DWG)

The instrument enclosure at the top of unit contains the microtuf[®] Switch electronics board which is removable to access the terminal block and facilitate field wiring (see Figure 4.0). For applications where the electronics must be located away from the sensors due to elevated process temperature, accessibility, etc., another instrument head containing the electronics is remotely located (See option RE-Remote Electronics section 3.2.2).




FIGURE 4 microtuf[®] SWITCH ASSEMBLY (MTF400.DWG/.FCW)

This page left blank intentionally.

3.0 INSTALLATION

3.1 Mechanical Installation

The standard microtuf[®] Switch has a .75 inch (19.05mm) MNPT mount designed for easy installation through a threaded port. Optional configurations include .5" (12.7mm) or 1.0" (25.4mm) MNPT and flange mounts. Conduit is recommended for all wiring to the switch.

IMPORTANT


WHEN INSTALLING YOUR DELTA M SWITCH INTO A PIPE OR VESSEL USE A 1 1/8 INCH (28.575mm) OPEN-END OR ADJUSTABLE WRENCH TO TIGHTEN AT THE HEX FLATS OF THE MNPT OF A STANDARD SWITCH. (IF YOU HAVE A NON-STANDARD SWITCH AN ALTERNATE SIZE WRENCH MAY BE REQUIRED). DO NOT USE THE INSTRUMENT HEAD TO TIGHTEN THE SWITCH TO THE MOUNTING PORT. ROTATION OF THE INSTRUMENT HEAD WITH RESPECT TO THE SENSOR BODY CAN CAUSE INTERNAL WIRING DAMAGE.

IMPORTANT

THE SWITCH BODY MUST BE ORIENTED TO HAVE THE TWIN SENSORS PROPERLY ORIENTED. DUE TO THE PIPE THREAD MOUNTING, IT MAY BE NECESSARY TO MAKE A TRIAL FIT, ADD OR REMOVE TEFLON TAPE OR OTHER PIPE THREAD SEALANT, AND REINSTALL TO ACHIEVE A SATISFACTORY SEAL WITH THE SENSORS PROPERLY ORIENTED. PROPER ORIENTATION IS MARKED ON THE SWITCH BODY FOR REFERENCE. SEE FIGURE 5.0 FOR DETAILS.

IMPORTANT


FOR OPTIMUM PERFORMANCE OF THE DELTA M THERMAL FLOW SWITCH, THE RECOMMENDED LOCATION OF THE SENSOR SHOULD BE IN A STRAIGHT RUN, FREE OF OBSTRUCTION, FOR TEN(10) TIMES THE PIPE DIAMETER UPSTREAM OF THE SENSOR AND FIVE (5) TIMES THE PIPE DIAMETER DOWNSTREAM OF THE SENSOR.




LEVEL APPLICATION FOR VERTICAL MOUNTING



VIEW A-A



FLOW APPLICATION




LEVEL APPLICATION FOR HORIZONTAL MOUNTING



VIEW B-B

NOTES:

- THE ARROWS ON THE FLATS OF THE MOUNTING FITTING INDICATES:
1. FOR FLOW APPLICATION—THE DIRECTION OF FLOW.
 2. FOR LEVEL APPLICATION WITH HORIZONTAL MOUNTING—THE DIRECTION OF VERTICAL TO THE LEVEL SURFACE.
 3. FOR LEVEL APPLICATION WITH VERTICAL MOUNTING—THE DIRECTION OF THE ARROW HAS NO SIGNIFICANCE.



VIEW C-C

DRAWING FILE: MTF500.DWG

FIGURE 5: PROPER ORIENTATION OF THE SENSOR PROBE FOR LEVEL AND FLOW APPLICATION IS INDICATED BY THE ARROW ON THE FLAT OF THE MOUNTING FITTING. (MTF500.DWG/FCW)

3.2 Electrical Installation

3.2.1 Local Electronics (LE Option/Standard)

Remove the instrument enclosure lid by unscrewing in a counter clockwise direction. Unscrew (CCW) the printed circuit board captive screws (See Figure 4.0 for locations). Remove the PC board by grasping the transformer and pulling it straight out. Connect power and alarm relay wiring to Terminal Block (TBB) as shown in Figure 6.0. Reinstall the microtuf[®] Switch electronics and tighten the captive screws.




FIGURE 6.0 microtuf[®] SWITCH LOCAL ELECTRONICS FIELD WIRING DIAGRAM (MTF600FCW/.DWG)

NOTES:

1. Connections to sensors terminal block A (TBA) are factory installed and should not be disconnected in the field. Note Jumpers 1-2, 3-4, and 5-6 must be in place on TBA for proper operation of local electronics.
2. For 24 VDC operation (factory prepared), connect +positive to TBB7 and –negative return to TBB8. For 110 VAC or 220 VAC connect hot to TBB7 and neutral to TBB8.
3. Connect ground wire to ground screw located in or on the instrument enclosure.
4. Use supply wires suitable for 10 Degrees C above ambient.

IMPORTANT

A GROUND WIRE MUST BE ATTACHED TO THE GROUND SCREW LOCATED INSIDE OR OUTSIDE OF THE INSTRUMENT ENCLOSURE FOR PROPER OPERATION.

3.2.2 Remote Electronics (RE Option)

For the remote electronics option, mount the remote instrument head using two mounting wings or bracket provided. Connect the switch wiring between the microtuf[®] Switch remote electronics as shown in Figure 7.0. Connect power wiring and alarm relay wiring to the remote enclosure as shown in Figure 7.0. Upon completion of wiring reinstall the microtuf[®] Switch electronics and secure with the captive screws.


IMPORTANT

BE SURE TO APPLY THE PROPER VOLTAGE AS CONFIGURED AT THE FACTORY. DO NOT APPLY 110 VAC TO 24 VDC VERSIONS OR 24 VDC TO 110 VAC VERSIONS (LIKEWISE 220 VAC). NOTE THAT ALL VOLTAGES ARE NOMINAL.

SPECIAL NOTICE

The electronic assemblies contained in the microtuf[®] models are configured for specific voltages and have specific modifications to accommodate the various agency approvals. When ordering spare electronics, replacements, or exchanges in the field please ensure you identify the specific configuration you have by noting the boxes marked on the transformer configuration tag and the serial number.

PN 200203		
<input type="checkbox"/> 	<input type="checkbox"/>	<input type="checkbox"/> 24 VAC
<input type="checkbox"/> 	<input type="checkbox"/>	<input type="checkbox"/> 24 VDC
<input type="checkbox"/> 	<input type="checkbox"/>	<input type="checkbox"/>
<input type="checkbox"/> SN <input style="width: 100px;" type="text"/>	<input type="checkbox"/> 220 VAC	<input type="checkbox"/> 110 VAC



NOTES:

1. JUMPER WIRES 1-2, 3-4, AND 5-6 MUST BE IN PLACE ON TBC IN THE REMOTE PROBE FOR PROPER OPERATION OF THE REMOTED ELECTRONICS.
2. FOR 24VDC OPERATION (FACTORY PREPARED), CONNECT + POSITIVE TO TBB7 AND - NEGATIVE RETURN TO TBB8. FOR 115VAC OR 230 VAC CONNECT HOT TO TBB7 AND NEUTRAL TO TBB8.
3. CONNECT GROUND WIRE TO GROUND SCREW LOCATED IN OR ON THE INSTRUMENT ENCLOSURE.
4. USE SUPPLY WIRES SUITABLE FOR 10 DEGREE C ABOVE AMBIENT.

FIGURE 7A microtuf® FLOW SWITCH REMOTE ELECTRONICS OPTION FIELD WIRING DIAGRAM (MTF701.DWG/FCW)

3.2 Electrical Installation

3.2.3 CE Option Filter Board Connector Plate Wiring (CE Option)

Remove the instrument enclosure lid by unscrewing in a counter clockwise direction. Unscrew (CCW) the printed circuit board captive screws (See Figure 4.0 for locations). Remove the PC board by grasping the transformer and pulling it straight out. Connect power and alarm relay wiring to Power Block as shown in Figure 6A. Reinstall the microtuf[®] Switch electronics and tighten the captive screws.




FIGURE 6A microtuf[®] SWITCH REMOTE ELECTRONICS FIELD WIRING DIAGRAM (MTF6A00FCW/.DWG)

NOTES:

1. Connections to sensors terminal block A (TBA) are factory installed and should not be disconnected in the field. Note Jumpers 1-2, 3-4, and 5-6 must be in place on TBA for proper operation of local electronics.
2. For 24 VDC operation (factory prepared), connect +positive to TBB7 and –negative return to TBB8. For 110 VAC or 220 VAC connect hot to TBB7 and neutral to TBB8.
3. Connect ground wire to ground screw located in or on the instrument enclosure.
4. Use supply wires suitable for 10 Degree C above ambient.

IMPORTANT

A GROUND WIRE MUST BE ATTACHED TO THE GROUND SCREW LOCATED INSIDE OR OUTSIDE OF THE INSTRUMENT ENCLOSURE FOR PROPER OPERATION.

This page left blank intentionally.

4.0 OPERATION AND CALIBRATION OF THE microtuf® FS4200 SWITCH FOR FLOW APPLICATIONS

4.1 Pre-Operational Check

With the switch installed and process conditions at no-flow, the following procedure can be used to verify preliminary operation.

- 4.1.1 Remove the instrument enclosure cover by turning counter clockwise (ccw) to expose the microtuf® Switch electronics.
- 4.1.2 Turn on power at its source.
- 4.1.3 Observe that either the red or green LED comes on.
- 4.1.4 If neither lamp illuminates refer to the trouble shooting Section, 6.2.


4.2 L.E.D. and Relay Status Logic (Fail-safe)

4.2.1 The L.E.D.s (Red; Green) are an indication of the sensors status (ie. flow below the setpoint or flow above the set point) and are not affected by the position of the failsafe jumper J-2. The failsafe jumper J-2 changes the relay activation status allowing the user to select the failsafe power off condition most appropriate to the application. Refer to the tables below that show the logic conditions between the sensors, L.E.D. lights, relay coil and contacts for each position of the failsafe jumper J-2.

4.2.2 Normal Operation (as set at factory)

The switch comes configured from the factory with the following operation with the J-2 jumper in the B(2-3) position. (Refer to Figure 8.0.)

<u>SENSOR STATUS</u>	<u>RED LED</u>	<u>GREEN LED</u>	<u>RELAY COIL STATUS</u>	<u>RELAY CONTACT STATUS</u>
No Flow or Flow Below Set Point	ON	OFF	Activated	<ul style="list-style-type: none"> o NC o NO
Flow or Flow Above Set Point	OFF	ON	Deactivated	<ul style="list-style-type: none"> o NC o NO



DRAWING FILE: MTF800.DWG/.FCW

FIGURE 8.0 microtuf® SWITCH ELECTRONICS (MTF800.FCW/DWG)

4.2.3 Alternate Operation (Field Selectable)

The relay logic may be reversed by moving the J-2 jumper to position A(1-2). (Refer to Figure 8.0.)

<u>SENSOR STATUS</u>	<u>RED LED</u>	<u>GREEN LED</u>	<u>RELAY COIL STATUS</u>	<u>RELAY CONTACT STATUS</u>
No Flow or Flow Below Set Point	ON	OFF	Deactivated	<input type="radio"/> NC <input type="radio"/> NO
Flow or Flow Above Set Point	OFF	ON	Activated	<input type="radio"/> NC <input type="radio"/> NO




FIGURE 9.0 microtuf® FS4200 FLOW SWITCH CALIBRATION REFERENCE DRAWING (MTF900.DWG.FCW)

4.3 Calibration – Flow

****IMPORTANT****
FOR OPTIMUM OPERATION, CALIBRATION MUST BE ACCOMPLISHED AT ACTUAL PROCESS TEMPERATURE AND PRESSURE CONDITIONS IN GASES AND AT ACTUAL PROCESS TEMPERATURE CONDITIONS IN LIQUIDS.

See Figures 8.0 and 9.0 for location of potentiometers and LEDs on electronics PCB.

4.3.1 Calibration Procedure for Flow Switches

1. Remove the instrument enclosure lid by turning ccw.
2. Apply power to FS4200. **Allow 10 minute warm-up.**
3. Ensure that the pipeline is filled with fluid and at no or minimum flow.
4. Set the trip adjust pot to zero fully counterclockwise (fully ccw).
5. Adjust the zero adjust pot so that the Red LED just does illuminate. This is a 25 turn pot. If the Green LED is on, turn the pot ccw. If the Red LED is on, turn the pot clockwise (cw).
6. Toggle the zero adjust pot back and forth until the switching point is well defined. Leave the Red LED illuminated.
7. Adjust the liquid or gas flow to maximum velocity. Insure that the flow is homogenous, constant and free of bubbles if a liquid.

****NOTE****

The flow rate (maximum) should be at least 5 fps (Hydrocarbons), 2.5 fps (water), or 500 fps (gas/air) if possible for best calibration. It is possible to achieve a 5 fps set point in water if a span of 7 fps can be achieved.

TO ENSURE ACCURATE CALIBRATION AND AVOID SET POINT DRIFT, IT IS IMPERATIVE THAT A MINIMUM OF **10 MINUTE WAIT** BE OBSERVED AFTER POWER IS APPLIED TO ALLOW THE SENSOR TO WARM-UP TO THE AMBIENT FLUID TEMPERATURE.

LIKEWISE, WHEN ADJUSTING THE ZERO, SPAN, AND SET POINT POTS, A **MINIMUM OF 30 SECONDS** SHOULD BE OBSERVED TO ALLOW FOR STABILIZATION OF TEMPERATURE.

8. Set the trip adjust pot to 100 (fully cw).
9. Adjust the span adjust pot so that the Green LED just does illuminate. This is a 25 turn pot. If the Green LED is on, turn the pot cw. If the Red LED is on, turn the pot ccw.
10. Toggle the span adjust pot back and forth until the switching point is well defined. Leave the Green LED illuminated.
11. If the switch is to be used for flow - no flow, set the trip adjust pot to 50 and go to step 14. (Note: This adjustment can be set for tripping points between 10% and 90% of the span from no flow to max flow).
12. A more exact flow rate setting may be made by establishing the flow at the desired rate with a separate flow meter and proceeding to step 13, to establish the trip point.

13. Adjust the trip adjust pot to obtain a trip as exhibited by an LED illumination. If a trip on decreasing flow is desired set for Red LED illumination. If a trip on increasing flow is desired set for Green LED illumination.
14. Verify that the switch will reset by returning the actual product flow to the maximum or minimum flow rates.

5.0 OPERATION AND CALIBRATION OF THE microtuf® LS3200 SERIES SWITCH FOR POINT LEVEL APPLICATIONS

5.1 Pre-Operational Check

The switch is installed **and the product level is below sensor level (dry)**, the following procedure can be used to verify preliminary operation.

1. Remove the instrument enclosure cover by turning counter clockwise to expose the LS3200 Switch electronics.
2. Turn on power at its source.
3. Observe that either the red or green LED comes on.
4. If neither lamp illuminates refer to the trouble shooting Section, 6.2.

5.2 L.E.D. and Relay Status Logic (Fail-Safe)

5.2.1 The L.E.D.s (Red and Green) are an indication of the sensors status (ie. dry or wet) and are not affected by the position of the fail-safe jumper J-2. The fail-safe jumper J-2 changes the relay activation status allowing the user to select the fail-safe power off condition most appropriate to the application. Refer to the tables below that show the logic conditions between the sensors, L.E.D. lights, relay coil and contacts for each position of the fail-safe jumper J-2.

5.2.2 Normal Operation (as set at factory)

The switch comes configured from the factory with the following operation with the J-2 jumper in the B (2-3) position. (Refer to Figure 8.0.)

<u>SENSOR STATUS</u>	<u>RED LED</u>	<u>GREEN LED</u>	<u>RELAY COIL STATUS</u>	<u>RELAY CONTACT STATUS</u>
Dry, or Lower Thermal Dispersion Fluid (i.e. hydrocarbons)	ON	OFF	Activated	<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">o NC</div> <div style="margin-right: 10px;">↘</div> <div>o NO</div> </div>
Wet, or Higher Thermal Dispersion Fluid (i.e. water)	OFF	ON	Deactivated	<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">o NC</div> <div style="margin-right: 10px;">↗</div> <div>o NO</div> </div>

5.2.3 Alternate Operation (Field Selectable)

The relay logic may be reversed by moving the J-2 jumper to position A(1-2). (Refer to Figure 8.0.)

SENSOR STATUS	RED LED	GREEN LED	RELAY COIL STATUS	RELAY CONTACT STATUS
Dry, or Lower Thermal Dispersion Fluid (i.e. hydrocarbons)	ON	OFF	Deactivated	<input type="radio"/> NC <input type="radio"/> NO
Wet, or Higher Thermal Dispersion Fluid (i.e. water)	OFF	ON	Activated	<input type="radio"/> NC <input type="radio"/> NO




FIGURE 8.0 microtuf® SWITCH ELECTRONICS (MTF800.FCW.DWG)

5.3 Calibration – Level

****IMPORTANT****

FOR OPTIMUM OPERATION CALIBRATION MUST BE ACCOMPLISHED AT ACTUAL PROCESS TEMPERATURE CONDITIONS.




FIGURE 10.0 microtuf® LS3200 POINT LEVEL SWITCH CALIBRATION REFERENCE DRAWING (MTF1000.DWG/FCW)

5.3 Calibration - Level

Using Figure 10.0 as a location guide adjust the system as follows:

1. Remove the instrument enclosure lid by turning ccw.
2. Apply power to the unit. **Allow 10 minute warm-up.**
3. For optimum calibration results, wet sensor and drain but do not dry.
4. Ensure that the tank liquid level is below the probe sensor tips.
5. Set the trip adjust pot to zero, fully counterclockwise (fully ccw).

TO ENSURE ACCURATE CALIBRATION AND AVOID SET POINT DRIFT, IT IS IMPERATIVE THAT A MINIMUM OF **10 MINUTE WAIT** BE OBSERVED AFTER POWER IS APPLIED TO ALLOW THE SENSOR TO WARM-UP TO THE AMBIENT FLUID TEMPERATURE.

LIKewise, WHEN ADJUSTING THE ZERO, SPAN, AND SET POINT POTS, A **MINIMUM OF 30 SECONDS** SHOULD BE OBSERVED TO ALLOW FOR STABILIZATION OF TEMPERATURE.

6. Adjust the zero adjust pot so that the Red LED just does illuminate. This is a 25 turn pot. If the green LED is on, turn the pot counterclockwise (ccw). If red LED is on, turn the pot clockwise (cw).
7. Toggle the zero adjust pot back and forth until the switching point is well defined. Leave the Red LED illuminated.
8. Raise the level of the liquid to be detected until the probe/sensor tips are submerged and wet (covered).
9. Set the trip adjust pot to 100 (fully cw).
10. Adjust the span adjust pot so that the Green LED just does illuminate. This is a 25 turn pot. If the Green LED is on, turn the pot cw. If the Red LED is on, turn the pot ccw.
11. Toggle the span adjust pot back and forth until the switching point is well defined. Leave the green LED illuminated.
12. Adjust the trip adjust pot to 80 and the calibration is complete. Setting this pot to 80 gives an approximate equal trip time from wet to dry and from dry to wet. Setting this pot closer to zero will speed up dry to wet trip time and slow down wet to dry trip time. Setting this pot closer to 100 will slow down the dry to wet trip time and speed up wet to dry trip time.

6.0 MAINTENANCE AND TROUBLE SHOOTING

6.1 Cleaning

The switch can be cleaned by soaking, spraying solvents or detergent-and-water onto the sensor tubes, or by ultrasonic cleaning.

Lime deposits can be safely removed by soaking in 20% hydrochloric acid. Warming to 150°F is permissible to speed this process. The acid must be thoroughly rinsed off once cleaned.

For unusual cleaning problems, call DELTA M and determine the exact materials of construction and chemical compatibility before using strong acids or unusual cleansers.

****IMPORTANT****

**DO NOT SANDBLAST OR ABRASIVE CLEAN THE SENSING PROBES.
THE SENSING PROBES COULD BE DAMAGED BY ABRASIVES.**

6.2 Troubleshooting

6.2.1 Power and Continuity Verification

1. Turn power off to the microtuf[®] Switch.
2. Remove the instrument enclosure cover (ccw).
3. Loosen the two PC captive screws (see Figure 4.0 for location).
4. Unplug the PC board from the instrument enclosure by pulling straight out on the transformer.
5. Reapply power and verify correct voltage at pins 7 (positive for DC) and 8 (negative for DC) of TBB (see Figures 6.0 or 7.0).
6. If voltage is correct, verify the fuse (F1) on the PC board is not blown (See Figure 8.0). If fuse is not blown proceed to 6.2.2.
7. If fuse is blown replace with appropriate value (See 7.0 Specification).

6.2.2 Sensor/Electronics Functionality Verification

1. Turn power off to microtuf[®] Switch.
2. Allow a 5 minute cool down.
3. Measure the resistance of each RTD at pins 1 and 6 of TBA (see Figure 6.0 or 7.0) for the hot RTD and pins 3 and 5 of TBA for the cold RTD. These resistances should be 110 ± 10 ohms (with sensors at approximately 70°F) and within 5% of each other in value.
4. Measure the insulation resistance between pin 1 of TBA and the case of the microtuf[®] Switch. It should be greater than 20 megohms.
5. If the microtuf[®] Switch sensor assembly resistances are not as specified above, the switch sensor assembly must be replaced.
5. If the microtuf[®] Switch sensor assembly resistances are as specified, the microtuf[®] Switch PC electronic board must be replaced.

6.2.3 Set Point Drift

TO ENSURE ACCURATE CALIBRATION AND AVOID SET POINT DRIFT, IT IS IMPERATIVE THAT A MINIMUM OF **10 MINUTE WAIT** BE OBSERVED AFTER POWER IS APPLIED TO ALLOW THE SENSOR TO WARM-UP TO THE AMBIENT FLUID TEMPERATURE.

LIKewise, WHEN ADJUSTING THE ZERO, SPAN, AND SET POINT POTS, A **MINIMUM OF 30 SECONDS** SHOULD BE OBSERVED TO ALLOW FOR STABILIZATION OF TEMPERATURE.

SPECIAL NOTICE

The electronic assemblies contained in the microtuf[®] models are configured for specific voltages and have specific modifications to accommodate the various agency approvals. When ordering spare electronics, replacements, or exchanges in the field please ensure you identify the specific configuration you have by noting the boxes marked on the transformer configuration tag.

PN 200203







SN



24 VAC

24 VDC

220 VAC 110 VAC

8.0 WARRANTY AND SERVICE

8.1 Warranty

DELTA M Corporation warrants microtuf® switches for a period of two years from the date of shipment and will repair or replace this product in the event of a defect in materials or workmanship. To have a product repaired, it should be returned at customer's expense, after obtaining return authorization as described in Section 8.2, to a repair facility designated by DELTA M and, after repair, DELTA M will prepay transportation to return the product to the customer. This limited warranty only covers failures due to defects in materials or workmanship which occur during normal use.

LIMITS AND EXCLUSIONS

DELTA M CORPORATION SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, LOSS OF USE, LOSS OF SALES, OR INCONVENIENCE) RESULTING FROM THE USE OF THESE PRODUCTS, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. EXCEPT AS SET FORTH ABOVE, THERE ARE NO EXPRESS OR IMPLIED WARRANTIES OR WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

8.2 Service

To receive prompt service call DELTA M's Customer Service Department at (865) 483-1569 or toll free 1-800-922-0083. A representative will assist you in determining if the unit must be returned to the factory. A Return Authorization Number (RAN) will be given and should be clearly visible on the outside of the returning package. **Prior to calling, be sure to have the model number and serial number information for quick identification and service response.**

In addition to the RAN, the Return Shipment Form should be attached to the packing list. This form is available at Delta M's website (www.deltamcorp.com), from the Customer Service Representative, or on page 33 of this manual. **The package will be returned unopened to the customer at the customer's expense if the Return Shipment Form and RAN are not present on the outside of the package.**

Because we serve a diverse customer base, there is a risk of receiving contaminated returned material from our customers. **When uncleaned material is received at Delta M, the item will be returned to the customer for cleaning at the customer's expense.**

NOTE:

TO ENSURE THE SAFETY OF SHIPPING CARRIERS AND DELTA M PERSONNEL, ANY PACKAGE THAT DOES NOT HAVE THE RETURN SHIPMENT FORM AND RETURN AUTHORIZATION NUMBER PRESENT ON THE OUTSIDE OF THE PACKAGE WILL BE RETURNED TO THE CUSTOMER AT THE CUSTOMER'S EXPENSE.

RETURN SHIPMENT



Ship to: Delta M Corporation
1003 Larsen Drive
Oak Ridge, TN 37830
Phone: (800) 922-0083
Fax: (865) 483-1142

If you believe your unit is not working properly, contact the Delta M Customer Service Department. Please have the following information ready to give to the Delta M Customer Service Representative:

*Defective Unit's Model Number: *Date:

*Defective Unit's Serial Number:

*Description of Application Unit was used in:

*Description of Type of Environment Unit was used in:

Description of Perceived Problem:

Special QA Requirements (nuclear or military application, oxygen service, special calibration or certification, etc.):

*Technical Contact's Name:

*Technical Contact's Phone Number:

*Complete Shipping Address:

*Complete Billing Address:

You will then be issued a RAN number. **Delta M personnel will refuse to accept return material shipments if a RAN number is not visible on the outside surface of the shipping container.**

*RAN (Return Authorization Number)

Cleaning of Material to be Returned

Thoroughly clean all material to be returned to Delta M. Because we serve a diverse customer base, there is a risk of receiving contaminated returned material from our customers. **When uncleaned material is received at Delta M, the item will be returned to the customer for cleaning at the customer's expense.**

Shipping Material to be Returned

Securely package cleaned material. **(When uncleaned material is received at Delta M the material will be returned.)** A packing list referencing the RAN number, model number and serial number should be in the sturdy shipping container with the return address and RAN number clearly marked on the outside surface of the container. **Delta M personnel will refuse to accept returns if a RAN number is not visible on the outside surface of the shipping container.**

*Required Fields

QSP-7.2-3

8.3 Spare Parts List

Part No. Description**Microtuf Electronics**

200203.1	FS42/LS32 – 110Vac
200203.2	FS42/LS32- 24Vdc
200203.3	FS42/LS32 - 220Vac
200203.5	FS42/LS32 w/ HS Relay (Specify Voltage)
200540.1	FS4100/LS3100 -110Vac
200540.2	FS4100/LS3100 - 24Vdc
200540.3	FS4100/LS3100 - 220Vac

Connector Plates

200202	FS42/LS32 –Local Electronics
200450	Remote Connector Plate
200182	Remote – MT & HT Options

Fuses

101603	FS42/LS32 - Wickmann 37402500410
101605	FS42/LS32-Cenelec Wickmann 37202500411

Manuals

101740	MicroTuf Manual
--------	-----------------

Enclosures

101790	Standard Enclosure
101797	Standard Enclosure w/ Cenelec Approval
101798	Standard Enclosure w/ Glass Window
101611	Enclosure for Failure Alarm Option-Std.
101612	Enclosure for Failure Alarm Option – Cenelec
101613	Enclosure for Failure Alarm Option-Glass Window

Cable

101567	Cable- Standard
101539	Cable- MT/HT Option

Sensor

200711	Sensor Assy. .75-S6-2.00
200087	Sensor Assy. 1.00-S6-2.00
N/A	Sensor Assy. .50-S6-2.00
N/A	Other determined by original part no.


9.1 VOLUME FLOW CONVERSION CHART

Convert known units to cubic feet per second (CFPS) or gallons per minute (GPM) for use with Chart A.2

<u>TO CONVERT FROM</u>	<u>TO</u>	<u>MULTIPLY BY</u>
Gallons Per Minute (GPM)	Cubic Feet Per Per Second (CFPS)	2.228 E-03
Gallons Per Day (GPD)	CFPS	1.547 E-06
Barrels Per Day (BPD)	CFPS	6.531 E-5
Cubic Ft. Per Minute (CFPM)	CFPS	1.667 E-02
Cubic In. Per Minute (CIPM)	CFPS	9.645 E-06
Milliliters Per Minute (MLPM)	CFPS	5.886 E-07
Milliliters Per Second (MLPS)	CFPS	3.531 E-05
Milliliters Per Hour (MLPH)	CPFS	9.810 E-09
Liters Per Day (LPD)	CPFS	4.087 E-07
Gallons Per Day (GPD)	GPM	6.944 E-04
Barrels Per Day (BPD)	GPM	2.931 E-02
Cubic Ft. Per Second (CFPS)	GPM	4.488 E+02
Cubic Ft. Per Minute (CFPM)	GPM	7.481
Cubic In. Per Minute (CIPM)	GPM	4.329 E-03
Milliliters Per Minute (MLPM)	GPM	2.642 E-04
Milliliters Per Second (MLPS)	GPM	4.403 E-06
Milliliters Per Hour (MLPH)	GPM	1.585 E-02
Liters Per Day (LPD)	GPM	1.835 E-04

9.2 FLOW CONVERSION CHART

FLOW CONVERSION CHART



THIS LINE CHART PROVIDES AN EASY METHOD FOR CONVERTING UNITS OF VOLUME FLOW. SIMPLY DRAW A LINE PERPENDICULAR TO THE SCALE LINES THROUGH A VALUE OF FLOW AND READ THE EQUIVALENT VALUE ON ANY OF THE OTHER SCALES.

9.3 FLOW OF WATER THROUGH SCHEDULE 40 STEEL PIPE

FLOW OF WATER
Flow of Water Through Schedule 40 Steel Pipe


Pressure Drop per 100 feet and Velocity in Schedule 40 Pipe for Water at 60 F.

Discharge		1/8"		1/4"		3/8"		1/2"		3/4"		1"		1 1/4"		1 1/2"	
Gallons per Minute	Cubic Ft. per Second	Veloc-ity Feet per Second	Press.-Drop Lbs. per Sq. In.	Veloc-ity Feet per Second	Press.-Drop Lbs. per Sq. In.	Veloc-ity Feet per Second	Press.-Drop Lbs. per Sq. In.	Veloc-ity Feet per Second	Press.-Drop Lbs. per Sq. In.	Veloc-ity Feet per Second	Press.-Drop Lbs. per Sq. In.	Veloc-ity Feet per Second	Press.-Drop Lbs. per Sq. In.	Veloc-ity Feet per Second	Press.-Drop Lbs. per Sq. In.	Veloc-ity Feet per Second	Press.-Drop Lbs. per Sq. In.
.2	0.000446	1.13	1.86	0.616	0.359												
.3	0.000668	1.69	4.22	0.924	0.903												
.4	0.000891	2.26	6.98	1.23	1.61	0.504	0.159	0.317	0.061								
.5	0.00111	2.82	10.5	1.54	2.39	0.672	0.345	0.422	0.086								
.6	0.00134	3.39	14.7	1.85	3.29	0.839	0.539	0.528	0.167	0.301	0.033						
.8	0.00178	4.52	25.0	2.46	5.44	1.01	0.751	0.633	0.240	0.361	0.041						
1	0.00223	5.65	37.2	3.08	8.28	1.34	1.25	0.844	0.408	0.481	0.102						
2	0.00446	11.29	134.4	6.16	30.1	2.68	6.58	1.68	1.85	1.06	0.600	0.602	0.155	0.371	0.048		
3	0.00668			9.25	64.1	4.02	13.9	2.11	2.10	1.20	0.526	0.743	0.164	0.429	0.044		
4	0.00891			12.33	111.2	5.04	13.9	3.17	4.33	1.81	1.09	1.114	0.336	0.644	0.090	0.473	0.043
5	0.01114			15.4	167.0	6.72	23.9	4.22	7.42	2.41	1.83	1.49	0.565	0.858	0.150	0.630	0.071
6	0.01337			18.5	250.0	8.40	36.7	5.28	11.2	3.01	2.75	1.86	0.835	1.073	0.223	0.788	0.104
8	0.01782			24.6	372.0	10.88	51.9	6.33	15.8	3.61	3.84	2.23	1.17	1.29	0.309	0.946	0.145
10	0.0223			30.8	544.0	13.44	91.1	8.45	27.7	4.81	6.60	2.97	1.99	1.72	0.518	1.26	0.241
15	0.03341			46.2	816.0	20.1	139.0	10.56	42.4	6.02	9.99	3.71	2.99	2.15	0.774	1.58	0.361
20	0.04456			61.6	1088.0	27.2	203.0	12.6	63.6	7.23	14.4	4.45	4.36	2.72	1.073	1.92	0.518
25	0.05570			77.0	1410.0	34.4	288.0	14.7	91.1	8.45	20.1	5.28	6.33	3.39	1.41	2.39	0.755
30	0.06684			92.4	1740.0	41.6	396.0	16.8	127.0	9.66	27.7	6.16	8.40	4.16	1.86	2.82	1.01
35	0.07798			107.8	2070.0	48.8	528.0	18.9	174.0	10.88	37.2	7.04	11.2	4.96	2.39	3.39	1.28
40	0.08912			123.2	2400.0	56.0	684.0	21.0	239.0	12.10	49.6	7.92	15.0	5.75	2.96	3.96	1.56
45	0.1003			138.6	2730.0	63.2	864.0	23.1	324.0	13.32	64.1	8.80	19.8	6.54	3.54	4.54	1.84
50	0.1114			154.0	3060.0	70.4	1068.0	25.2	432.0	14.54	81.6	9.66	25.8	7.33	4.11	5.11	2.12
60	0.1337			215.0	4080.0	92.4	1410.0	33.3	576.0	19.0	108.0	12.10	33.9	9.66	5.28	6.54	2.56
70	0.1560			276.0	5100.0	114.4	1800.0	41.4	756.0	23.4	144.0	14.54	44.0	11.2	6.98	7.92	2.96
80	0.1782			337.0	6120.0	136.4	2310.0	49.5	972.0	27.8	189.0	16.98	57.0	12.9	8.40	9.30	3.39
90	0.2005			398.0	7140.0	158.4	2916.0	57.6	1278.0	32.2	252.0	19.42	72.0	14.54	9.99	10.73	3.82
100	0.2228			459.0	8160.0	180.4	3528.0	65.7	1692.0	36.6	324.0	21.86	88.0	16.98	11.61	12.10	4.25
125	0.2785			570.0	10200.0	226.4	4536.0	81.6	2124.0	44.7	420.0	26.4	112.0	20.1	14.54	15.4	5.11
150	0.3342			681.0	12240.0	272.4	5544.0	97.5	2772.0	52.8	540.0	30.9	144.0	23.4	17.4	18.6	5.99
175	0.3899			792.0	14280.0	318.4	6552.0	113.4	3402.0	60.9	696.0	35.4	180.0	27.8	20.3	22.7	6.84
200	0.4456			903.0	16320.0	364.4	7560.0	129.3	4140.0	69.0	882.0	40.0	222.0	31.8	23.2	26.4	7.70
225	0.5013			1014.0	18360.0	410.4	8568.0	145.2	4968.0	77.1	1116.0	44.7	264.0	36.6	26.1	30.1	8.56
250	0.557			1125.0	20400.0	456.4	9576.0	161.1	5796.0	85.2	1380.0	48.4	306.0	41.4	29.0	33.9	9.42
275	0.6127			1236.0	22440.0	502.4	10584.0	177.0	6624.0	93.3	1692.0	52.1	354.0	46.0	31.8	37.7	10.28
300	0.6684			1347.0	24480.0	548.4	11592.0	192.9	7512.0	101.4	2016.0	55.8	402.0	50.7	34.7	41.4	11.14
325	0.7241			1458.0	26520.0	594.4	12600.0	208.8	8400.0	109.5	2352.0	59.4	450.0	54.4	37.7	45.2	12.00
350	0.7798			1569.0	28560.0	640.4	13608.0	224.7	9288.0	117.6	2700.0	63.0	504.0	58.0	40.6	48.8	12.86
375	0.8355			1680.0	30600.0	686.4	14616.0	240.6	10176.0	125.7	3060.0	66.6	558.0	61.6	43.5	51.1	13.72
400	0.8912			1791.0	32640.0	732.4	15624.0	256.5	11064.0	133.8	3420.0	70.2	612.0	65.2	46.0	54.4	14.58
425	0.9469			1902.0	34680.0	778.4	16632.0	272.4	12012.0	141.9	3780.0	73.8	666.0	68.8	48.4	57.0	15.44
450	1.003			2013.0	36720.0	824.4	17640.0	288.3	12960.0	150.0	4140.0	77.4	720.0	72.0	50.7	59.4	16.30
475	1.059			2124.0	38760.0	870.4	18648.0	304.2	13912.0	158.1	4500.0	81.0	774.0	75.6	52.8	61.6	17.16
500	1.114			2235.0	40800.0	916.4	19656.0	320.1	14868.0	166.2	4860.0	84.6	828.0	79.2	55.2	63.0	18.02
550	1.225			2447.0	44880.0	998.4	21312.0	346.0	16116.0	177.0	5340.0	91.4	906.0	82.4	59.4	68.4	19.20
600	1.337			2659.0	48960.0	1080.4	22968.0	371.9	17372.0	187.8	5820.0	98.2	984.0	85.6	63.0	72.6	20.38
650	1.448			2871.0	53040.0	1162.4	24624.0	397.8	18628.0	198.6	6300.0	105.0	1062.0	88.8	66.6	75.0	21.56
700	1.560			3083.0	57120.0	1244.4	26280.0	423.7	19884.0	209.0	6780.0	111.4	1140.0	92.0	69.8	77.4	22.74
750	1.671			3295.0	61200.0	1326.4	27936.0	449.6	21140.0	219.4	7260.0	117.8	1218.0	95.2	72.6	79.8	23.92
800	1.782			3507.0	65280.0	1408.4	29592.0	475.5	22396.0	229.8	7740.0	124.2	1296.0	98.4	75.6	81.6	25.10
850	1.894			3719.0	69360.0	1490.4	31248.0	501.4	23652.0	240.2	8220.0	130.6	1374.0	101.6	78.6	84.0	26.28
900	2.005			3931.0	73440.0	1572.4	32904.0	527.3	24908.0	250.6	8700.0	137.0	1452.0	104.8	81.6	86.4	27.46
950	2.117			4143.0	77520.0	1654.4	34560.0	553.2	26164.0	261.0	9180.0	143.4	1530.0	108.0	84.6	88.8	28.64
1000	2.228			4355.0	81600.0	1736.4	36216.0	579.1	27420.0	271.4	9660.0	149.8	1608.0	111.2	87.6	91.2	29.82
1100	2.451			4767.0	89760.0	1881.4	39372.0	626.0	29676.0	291.8	10380.0	156.2	1686.0	114.4	90.6	93.6	31.00
1200	2.674			5179.0	97920.0	2026.4	42528.0	672.9	31932.0	312.2	11100.0	162.6	1764.0	117.6	93.6	96.0	32.18
1300	2.896			5591.0	106080.0	2171.4	45684.0	719.8	34188.0	332.6	11820.0	169.0	1842.0	120.8	96.6	98.4	33.36
1400	3.119			6003.0	114240.0	2316.4	48840.0	766.7	36444.0	353.0	12540.0	175.4	1920.0	124.0	99.6	100.8	34.54
1500	3.342			6415.0	122400.0	2461.4	51996.0	813.6	38700.0	373.4	13260.0	181.8	2000.0	127.2	102.6	103.2	35.72
1600	3.565			6827.0	130560.0	2606.4	55152.0	860.5	40956.0	393.8	13980.0	188.2	2080.0	130.4	105.6	105.6	36.90
1800	4.010			7639.0	144720.0	2918.4	61416.0	956.4	45120.0	435.4	15180.0	201.0	2220.0	136.8	111.0	111.0	39.06
2000	4.456			8451.0	158880.0	3230.4	67680.0	1052.3	49284.0	477.0	16380.0	213.8	2360.0	143.2	116.4	116.4	41.22
2500	5.570			10573.0	198000.0	3936.4	84240.0	1284.0	59160.0	573.6	19500.0	250.2	2820.0	162.6	130.2	130.2	49.38
3000	6.684			12695.0	237120.0	4642.4	99804.0	1515.6	69036.0	670.2	22620.0	286.6	3280.0	177.0	144.6	144.6	57.54
3500	7.798			14817.0	276240.0	5348.4	115368.0	1747.2	78912.0	766.8	25740.0	322.6	3740.0	191.4	159.0	159.0	65.70
4000	8.912			16939.0	315360.0	6054.4	130932.0	1978.8	88788.0	863.4	28860.0	358.6	4200.0	205.8	173.4	173.4	73.86
4500	10.03			19061.0	354480.0	6760.4	146496.0	2210.4	98664.0	960.0	31980.0	394.6	4660.0	220.2	187.8	187.8	82.02
5000	11.14			21183.0	393600.0	7466.4	162060.0	2442.0	108540.0	1056.6	35100.0	430.6	5120.0	234.6	202.2	202.2	90.18
6000	13.37			25205.0	472800.0	8818.4	194124.0	2844.0	129636.0	1242.2	40260.0	498.2	5820.0	263.8	231.0	231.0	106.26
7000	15.60			29227.0	552000.0	10170.4	226188.0	3246.0	149732.0	1427.8	45420.0	565.8	6520.0	293.0	259.4	259.4	122.34
8000	17.82																

10.0 OPTIONS**10.1 LIVETAP (LT)**


Livetap (LT)

Specifications & Operating
Instructions



- Allows for the safe insertion and removal of DELTA M switches without interrupting the flow in your pipelines.
- For use with both the VERSA-SWITCH[®] and microtuf[®] line of DELTA M switches.
- External extraction gauge lets you know when the switch is clear of the valve.
- Standard Stainless Steel Construction.
- Operating temperature rating of 390° F. Allows for use in many high temperature applications.
- Dual safety restraint design to aid in the prevention of accidents.
- Live tap may be installed in both tanks and pipes without regard for orientation.
- Operating pressure rating of 300 psig.

DELTA M Corporation - 1003 Larsen Drive - Oak Ridge, Tennessee 37830 - USA - Phone: (865)483-1569 - Fax (865)483-1142 - <http://www.deltamcorp.com>



VERSA-SWITCH[®] and microtuf[®] Switch Option

Livetap (LT)

Operating Instructions

Installation

DELTA M's Livetap needs to be installed using industry standard piping practices. Install Livetap using the valve body (6) only to tighten.

Probe Insertion

First the valve handle (1) must be in the open position (handle turned so that it is parallel to the probe).

Second loosen nut (2) so that probe can be pushed into the pipe or tank by putting pressure on the switch head.

Third make sure that nut (3) touches nut (2). This ensures that the probe has been inserted the proper distance.

Fourth tighten nut (2). This will lock the probe in the inserted position.

Probe Removal

First loosen nut (2). This will allow for the removal of the switch from the flow stream by gently pulling on the switch head.


Second make sure that safety cable (4) is taut. This will ensure that the probe is clear of the valve.

Third close valve handle (1) (handle turned so that it is perpendicular to the probe).

Fourth loosen nut (5) completely. This will allow the probe with the larger diameter safety restraint assembly (7) to be removed from the valve assembly.


Form Number (DML 1008.02)

10.2 VARIABLE INSERTION (VI)



MAX PRESSURE AT TEFLON
SEAL IS 10 PSI


10.3 THERMOCOUPLE OUTPUT (TO) and 10.4 RTD OUTPUT (RT)



10.5 SANITARY (3A1)

DELTA 
CORPORATION

A **Sanitary Switch**
 Specifications & Operating
 Instructions



- DELTA M Corporation has received the authority to apply the 3-A symbol to our flow and level switches.
- For use with both the VERSA-SWITCH[®] and microtuf[®] line of DELTA M switches.
- Standard operating temperature range of -100°F to 390°F with options to 850°F.
- Standard Stainless Steel Construction.
- 3-A Authorization No. 950 issued to DELTA M by 3-A Sanitary Standards Symbol Administrative Council
- Designed for use in both food, beverage, and pharmaceutical applications.
- Available with insertion length to suit your specific level or flow application.
- Operating pressure rating of 1500 psig.

VERSA-SWITCH[®] & microtuf[®] Switch Option



* Shown Above with Optional Sanitary Tee

Operating Instructions

Installation

DELTA M's Sanitary Switch Option is to be installed using industry standard piping practices. Make sure that you have selected the proper gasket and clamp designed for your pressure, temperature and process fluid.

A 3 Sanitary Switch

SPECIFICATIONS

Sensor Type:

Thermal Differential, Dual RTD Sensors

Process Connection:

Standard 1.5 inch sanitary
Optionally 1.0 inch and larger

Insertion Length:

Standard 2.53 inch
Optionally custom length to suit your specific application.

Operating Temperature Range:

Standard -100°F to 390°F (-70°C to +200°C)

Medium temp to +572°F (+300°C)

High temp to +850°F (+458°C)

Materials of Construction:

Standard all welded 316L series stainless steel with nickel filler.

Operating Pressure Range:

Standard to 1500 psia (102 bar) with the proper clamp and gasket.

Operating Range:

Adjustable flow rate (feet per second - fps), typical: 0.01 to 5.0 fps liquids and 0.1 to 500 fps gases

Response Time:

Sensor response time 0.5 to 10 seconds media dependent

Stability:

Drift < .5% from calibrated setpoint over a range of $\pm 50^\circ$ F. Temperature compensated throughout entire range

Repeatability:

$\pm 1\%$ of setpoint

Form Number (DML1001.02)

10.6 SP76 MANIFOLD (S76)



DELTA **m**
CORPORATION

Time for a New Beginning
The DELTA **m** SP76 Mass Flow Switch
Helping Make Modular Sample Systems
Possible

DELTA M Corporation - 1003 Larsen Drive - Oak Ridge, Tennessee 37830 - USA - Phone: (865) 483-1569 - Fax (865) 483-1142 - <http://www.deltamcorp.com>

SP76 Compliant Mass Flow Switch

SPECIFICATIONS

Sensor

Type:

Thermal Differential, Dual RTD Sensors

Process Connection:

SP 76 Compliant 1.5 x 1.5 inch

Sensor Dimensions:

Height 4.4 inch

Width 1.5 inch

Length 1.5 inch

Operating Temperature Range:

Standard -100°F to 390°F (-70°C to +200°C)

Materials of Construction:

Standard 316L Series Stainless Steel

Operating Pressure Range:

Standard to 3000 psia (207 bar)

Electronics

Power:

Standard 110VAC Optionally 220VAC, or 24VDC at 3 watts (No heater power required)

Operating Temperature Range:

Standard -40°F to +140°F (-40°C to +60°C)

Outputs:

microtuf®

DPDT Relay contacts rated at 5 amp, 250 VAC with fail safe capability

VERSA-SWITCH®

Independent primary relay DPDT and secondary relay SPDT, contacts rated at 5 amp, 250 VAC with fail safe capability; built in time delay 0 to 300 seconds for each channel

Self-Test:

Integral and automatic during power up

Enclosure:

Explosion proof; NEMA 3, 4, 7, and 9; CSA, FM, UL, CENELEC, and EECS approved

Instrument

Operating Range:

Adjustable flow rate (feet per second - fps), typical: 0.01 to 5.0 fps liquids and 0.1 to 500 fps gases

Response Time:

Sensor response time 0.5 to 10 seconds media dependent

Stability:

Drift < .5% from calibrated setpoint over a range of ±50° F. Temperature compensated throughout entire range

Repeatability:

±1% of setpoint

Approvals:

Intrinsically Safe when used with IS option and proper barriers Class 1 Div. 1 Groups A,B, C, & D

Model Number Selection Guide

Code Model

VS5100 - Dual Channel VERSA-SWITCH
 VS51NX - Dual Channel Non Explosion Proof
 FS51SC - Single Channel Mass Flow Switch
 FS51NX - Single Channel Flow Non Explosion Proof
 FS42CS - CSA Approved Switch
 FS42CN - CENELEC Approved Switch
 FS42NX - Non Explosion Proof Switch

Code - Process Connection

S76 - SP76 Compliant

Code - Sensor Material

S6 - 316L Stainless Steel (std)

SM - Special Material

Code - Insertion Length

000.00 - 000.00 inch (std)

Code - Power Input

FLD - Field Config. (Versa only)

110 - 110 VAC

220 - 220 VAC

24D - 24 VDC

24A - 24 VAC (Versa only)

Code - Configuration

RE - Remote Electronics

Code - Special Option

QD - Quick Disconnect (Standard)

XW - X Proof Window

DS - Double Sided

FA - Failure Alarm

(VS5100 Only)

RT - RTD Output


TO - Thermocouple Out

CA - Additional Cable

CE - CE Approved

NP - Pipe Connection

FS42NX - S76 - S6 - 000.00 - 24D - RE - QD Model Number



10.7 TANK LOADING PROBE (TLP)

DELTA Truck & Rail Car CORPORATION Loading Sensor



DELTA M has a specially designed sensor for use in loading trucks and railcars. This unit has a quick locking clamp that attaches to the manhole and allows the probe to be adjusted to the desired level inside of the tank. These units can be used in hazardous areas and corrosive environments. The use of these sensors has been instrumental in preventing spills caused by accidental over filling and in preventing the time and cost involved in off loading material when a truck has been filled beyond its weight restrictions.

SPECIFICATIONS

Sensor

Type:

Thermal Differential, Dual RTD Sensors

Process Connection:

Automatically latching clamp

Insertion Length:

Standard 32.0 inch

Optionally 12 inch to 96 inches

Operating Temperature Range:

Standard -100°F to 390°F (-70°C to +200°C)

Medium Temperature to +572°F (+300°C)

Materials of Construction:

Standard 316L Series Stainless Steel

Optionally Hastelloy, Monel, Inconel and other exotic materials

Operating Pressure Range:

Standard to 3000 psia (207 bar)

Electronics

Power:

Standard 110VAC Optionally 220VAC, or 24VDC at 3 watts (No heater power required)

Operating Temperature Range:

Standard -40°F to +140°F (-40°C to +60°C)

Outputs:

microtuff®

DPDT Relay contacts rated at 5 amp, 250 VAC with fail safe capability

VERSA-SWITCH®

Independent primary relay DPDT and secondary relay SPDT, contacts rated at 5 amp, 250 VAC with fail safe capability; built in time delay 0 to 300 seconds for each channel

Self-Test:

Integral and automatic during power up

Enclosure:

Explosion proof; NEMA 3, 4X, 7, and 9; CSA, FM, UL, CENELEC, and EECs approved

Instrument

Operating Range:

Switch on level change of .03 inch. Available with insertion lengths from 12 to 96 inches.

Response Time:

Sensor response time 0.1 to 1 second media dependent

Stability:

Drift < .5% from calibrated setpoint over a range of ±50° F. Temperature compensated throughout entire range.

Repeatability:

±1% of setpoint

Approvals:

Optionally CE, CSA, CENELEC

Class 1 Div. 1 Groups B, C, & D when used with explosion proof cable and conduit.

Intrinsically Safe when used with IS option and proper

barriers Class 1 Div. 1 Groups A, B, C, & D

Code Model

VS5100 - Dual Channel VERSA-SWITCH

VS51NX- Dual Channel Non Explosion Proof

LS51SC - Single Channel Mass Flow Switch

LS51NX- Single Channel Flow Non Explosion Proof

LS32CS - CSA Approved Switch

LS32CN - CENELEC Approved Switch

LS32NX - Non Explosion Proof Switch

Code - Process Connection

TLP - Truck Loading Probe

Code - Sensor Material

S6 - 316L Stainless Steel (std)

HB - Hastelloy B

HC - Hastelloy C

IO - Inconel 600

MN - Monel

A2 - Alloy 20

SM - Special Material

Code - Insertion Length

32.00 -32.00 inch (std)

00.00 - 12" to 96.00" in .25"

Code - Power Input

FLD - Field Config. (Versa only)

110 - 110 VAC

220 - 220 VAC

24D - 24 VDC

24A - 24 VAC (Versa only)

Code - Configuration

RE-Remote Electronics (std)

RC-Remote Control Unit

Code - SpecialOption

CO- Clamp On (std)

XW- X proof Window

DS - Double Sided

FA - Failure Alarm

(VS5100 Only)

RT - RTD Output

TO-Thermocouple Out

CA - Additional Cable

CE - CE Approved

XC- X Proof Cable

LS32NX - TLP - S6 - 32.00 - 24D - RE - CO Model Number

Represented In Your Area By

Form Number (DML 1016.00)

DELTAM Corporation - 1003 Larsen Drive - Oak Ridge, Tennessee 37830 - USA - Phone: (865) 483-1569 - Fax (865) 483-1142 - <http://www.deltamcorp.com>

10.8 LOW FLOW (LF)

DELTA 
CORPORATION

Low Flow Sensor



- Developed for low flow gas and liquid applications where reliability and durability are mandatory
- Very low internal volume so that sample times are very short and sample system response remains quick
- All Welded Stainless Steel Construction
- For use with both the **VERSA-SWITCH**[®] and **microtuf**[®] line of DELTA M switches
- Standard operating temperature range of -100° F to 390° F
- 1/4 inch FNPT process ports that can easily be adapted to tubing by using standard fittings

SPECIFICATIONS

Sensor

Type:

Thermal Differential, Dual RTD Sensors

Process Connection:

1/4" FNPT (2) Inlet and Outlet

Operating Temperature Range:

Standard -100°F to 390°F (-70°C to +200°C)

Material of Construction:

Standard 316L Series Stainless Steel

Operating Pressure Range:

Standard to 3000 psia (207 bar)

Electronics

Power:

Standard:110VAC, Optionally: 220VAC, 24VDC or 24VAC at 3 watts (No heater power required)

Operating Temperature Range:

Standard -40°F to +140°F (-40°C to +60°C)

Outputs:

microtuf®

DPDT Relay contacts rated at 5 amp, 250 VAC with fail safe capability

VERSA-SWITCH®

Independent primary relay DPDT and secondary relay

SPDT, contacts rated at 5 amp, 250 VAC with fail safe capability; built in time delay 0 to 300 seconds for each channel

Self-Test:

Integral and automatic during power up

Enclosure:

Explosion proof; NEMA 3, 4X, 7, and 9; CSA, FM, UL, and EECs approved


Instrument

Operating Range:

.33ccm to 2000ccm in liquid and 30ccm to 200,000ccm in gas

Approvals:

Optionally CE, CSA, Class 1 Div. 1 Groups B, C, & D



INTERNAL VOLUME= 0.038 in³

Form Number (DML 1018.00)

DELTA M Corporation - 1003 Larsen Drive - Oak Ridge, Tennessee 37830 - USA - Phone: (865)483-1569 - Fax (865)483-1142 - <http://www.deltamcorp.com>

Model Number Selection Guide

Code Model

VS5100 - Dual Channel VERSA-SWITCH

VS51NX- Dual Channel Non Explosion Proof

FS51SC - Single Channel Mass Flow Switch

FS51NX- Single Channel Flow Non Explosion Proof

FS42CS - CSA Approved Switch

FS42NX - Non Explosion Proof Switch

Code - Process Connection

LFS - Low Flow Sensor

Code - Sensor Material

S6 - 316L Stainless Steel (std)

Code - Insertion Length

00.00 - None

Code - Power Input

FLD - Field Config. (Versa only)

110 - 110 VAC

220 - 220 VAC

24D - 24 VDC

24A - 24 VAC

Code - Configuration

LE-Local Electronics (std)

RE-Remote Electronics

Code - Special Option

OO - No Special Option

XW- X Proof Window

PC - Potted Cable

FA - Failure Alarm

(VS5100 Only)

RT - RTD Output

TO-Thermocouple Out

CA - Additional Cable

CE - CE Approved

(microtuf® Only)

QD - Quick Disconnect

CB - Calibration req.

FS42CS - LFS - S6 - 00.00 - 110 -LE-00 Model Number

Represented In Your Area By


This page left blank intentionally.

10.9 LIQUID LEVEL MULTI-POINT (MD/MP)

DELTA Liquid Level Multi-Point

Single Insertion 2 To 6 Points

- Built to suit your specific needs.
- Number of points and location determined by customer.
- Switch points are independent of each other.
- Local or remote electronics.
- Removable, plug in electronics.
- All welded materials of construction 316L Stainless Steel (std).



- Free of all moving parts that can stick, coat or fail.
- Fast response time of .1 to 1 second on wetting, media dependent.
- Switch on level change of .03 inch without concern for changing temperature, density, dielectric constant or chemical composition.
- Self heating sensor design improves repeatability and reliability. No separate heater to fail or slow response time.
- Wide operating temperature range -100°F to +572°F (-70°C to +300°C).
- Temperature compensation circuitry eliminates false switching due to process temperature changes.
- Both the **VERSA-SWITCH**® and **microtuf**® families of multi-point level switches can provide a solution for your demanding point level applications.

MODEL LM51NX MODEL LM32NX

SPECIFICATIONS

Sensor

Type:
Thermal Differential, dual RTD sensors with no separate heater

Process Connection:
Standard 1.50 inch MNPT
Optionally larger MNPT and flanges

Insertion Length:
Minimum 3.5 inches
Optionally Up to 120.0 inches

Operating Temperature Range:
Standard -100°F to 390°F (-70°C to +200°C)
Medium Temperature to +572°F (+300°C)

Materials of Construction:
Standard 316L Series Stainless Steel (std)

Operating Pressure Range:
Standard to 3000 psia (207 bar)

Electronics

Power:
110VAC, 220 VAC, or 24 VDC at 3 watts (No heater power required)

Operating Temperature Range:
Standard -40°F to +140°F (-40°C to +60°C)
Optionally remote electronics for use in medium temperature environments

Outputs Per Switch Point:
Independent relay DPDT, contacts rated at 5 amp, 250 VAC with ability to set fail safe mode

Self-Test:
Integral and automatic during power up

Enclosure:
Choice of local explosion proof with; NEMA 3, 4, 4X, 7, and 9; CSA, FM, UL, CENELEC, and EECS approvals or non explosion proof local or remote


Instrument

Response Time:
Sensor response time 0.5 to 10 seconds media dependent


Response to Level Change:
Will respond to a level change as small as .03 inch.

Repeatability:
±1% of set point

Model Number Selection Guide



Notes: (VS) VERSA-SWITCH® only option
(_ pt) Maximum number of points for option




Form Number (DML 1007.03)

10.10 SWITCH KITS (SK)

DELTA Switch Kit(SK)

Versa-Switch® & microtuf®
For Both Flow & Level Applications



This product line is designed for organizations that are building their own systems and have no need for the housings normally associated with industrial instrumentation. By eliminating the housing you not only save space but you also reduce the cost of the instruments. The removable plug in electronics allows you to incorporate these switches into your systems in such a way that the electronics remain easily removeable and replaceable without disturbing your wiring system. Our mounting plates are also available for DIN rail applications to further simplify installations.

- Both VERSA-SWITCH® and microtuf® family of switches are available.
- Handles both Mass flow and level switching applications equally well.
- Temperature outputs also available.
- All Welded Stainless Steel Constructon
- Free of all moving parts that can stick, coat or fail.
- Self heating sensor design improves repeatability. No separate heater to fail or slow response time.
- Removable, plug in electronics.

Switch Kit

SPECIFICATIONS

Sensor

Type:

Thermal Differential, dual RTD sensors with no separate heater

Process Connection:

Standard 0.75 inch MNPT

Optionally 0.25 inch and larger NPT and various other process connections such as sanitary, SP76, Low Flow and flanges

Insertion Length:

Standard 2.0 inch

Optionally 0.5inch or greater

Operating Temperature Range:

Standard -100°F to 390°F (-70°C to +200°C)

Materials of Construction:

Standard 316L Series Stainless Steel

Optionally Hastelloy, Monel, Inconel and other exotic materials

Operating Pressure Range:

Standard to 3000 psia (207 bar)

Electronics

Power:

Standard 110VAC Optionally 220VAC, 24VAC, or 24VDC at 3 watts (No heater power required)

Operating Temperature Range:

Standard -40°F to +140°F (-40°C to +60°C)

microtuf®

Outputs:

DPDT Relay contacts rated at 5 amp, 250 VAC with fail safe capability

VERSA-SWITCH®

Independent primary relay DPDT and secondary relay SPDT, contacts rated at 5 amp, 250 VAC with fail safe capability; built in time delay 0 to 300 seconds on each channel

Self-Test:

Integral and Automatic during power up

Instrument

Operating Range:

Adjustable Flow Rate (feet per second - fps), typical: 0.01 to 5.0 fps liquids and 0.1 to 500 fps gases

Response Time:

Sensor response time 0.5 to 10 seconds media dependent

Stability:

Drift < .5% from calibrated setpoint over a range of $\pm 50^\circ$ F. Temperature compensated throughout entire range

Repeatability:

$\pm 1\%$ of setpoint

Approvals:

Switch Kits carry no approvals.

Model Number Selection Guide

Code - Model	
V551SK - Dual Channel VERSA-SWITCH	
FS51SK - Single Channel Mass Flow VERSA-SWITCH	
LS51SK - Single Channel Point Level VERSA-SWITCH	
FS42SK - Microtuf Flow Switch	
LS32SK - Microtuf Level Switch	
Code - Process Connection	
3A1 - 1.5 Inch Sanitary w/ 3A Stamp	
075 - 0.75 Inch MNPT (std)	
050 - 0.50 Inch MNPT	
100 - 1 Inch MNPT	
RA1 - Raised Face Flange 150 # 1 Inch	
RA2 - Raised Face Flange 150 # 2 Inch	
RB1 - Raised Face Flange 300 # 1 Inch	
RB2 - Raised Face Flange 300 # 2 Inch	
LFS - Low Flow Sensor	
S76 - SP76 Sensor	
SPL - Special	
Code - Sensor Material	
S6 - 316L Stainless Steel (std)	
S4 - 304 Stainless Steel	
SL - 304L Stainless Steel	
HB - Hastelloy B	
HC - Hastelloy C	
IO - Inconel 600	
MN - Monel	
A2 - Alloy 20	
SM - Special Material	
Code - Insertion Length	
002.00 - 2.00 Inch (std)	
000.00 - 0.50" to 120.00" in .25 Increments	
000.00 - Custom Length	
Code - Power Input	
FLD - Field Configurable (Versa only)	
110 - 110 VAC	
220 - 220 VAC	
24D - 24 VDC	
24A - 24 VAC	
Code - Configuration	
PM - Plate Mount (std)	
DM - DIN Rail Mount	
Code - Special Options	
00 - No Special Option	
CB - Calibration Required	
VI - Variable Insertion	
LT - Live Tap	
FA - Failure Alarm (V55100 only)	
QD - Cable Quick Disconnect	
SR - Cable Strain Relief	
RT - RTD Output	
TO - Thermocouple Output	
CA - Additional PVC Cable	
V551SK- 075-S6-002.00- LD - PM - 00	Model Number
Represented In Your Area By	

Form Number (DML 1019.00)